

Product

Embla RA VBC



Embla RA VBC is a self adjusting stripping and cutting tool, 0.1-4 mm²/AWG 28-12, V-blade.

- Pistol grip provides stress free comfort, particularly when operating parallel to a table or workbench.
- Tool-less interchangeable stripping cassettes allow a wide and diverse stripping capacity
- Widest stripping capacity of any tool of its type
- Durable, integrated wire cutting capability
- Cutting capacity: Flexible wires, 10 mm²/8 AWG. Rigid wires, 1.5 mm² /16 AWG
- Fine adjustability for thin or thick insulation, without damage to wire conductors
- At the end of the stripping function, the stripping blades open and remain open to facilitate easy and snag free wire removal from the tool
- Ergonomic: strong, durable, and comfortable ergonomic design
- Replacement stripping cassettes and cutting blades available.
- Reliable: Frame and mechanism life span exceeds 150,000 cycles (tested with 1.5 mm²/AWG 16 PVC cable).

TECHNICAL DATA

Length: 144 mm/5.67"

Width: 23 mm/0.9"

Height: 168 mm/6.61"

Weight: 165 gr/0.37 lb

Wire size: 0.1-4 mm² / AWG 28-12

Stripping dimensions mm/mm²:
3-18 mm/adjustable

Stripping dimensions inch/AWG:
0.12-0.71/adjustable

Cable: PVC/PTFE and similar

Description: Self-adjusting cutting and stripping tool for electrical installation and equipment wires in PVC and PTFE insulation. V blade knives for easier strip cycle with hard insulations.

Life span, cycles: 150,000 (tested with 1.5 mm²/AWG 16 PVC cable)

All three cassettes (grey, red and blue) are available as separate items.

