

Product

Tor



Tor is an adjustable heavy-duty cable stripping tool for all insulation types. Unique features with interchangeable cable retention hooks giving it cable stripping capacity of up to 40 mm/1.57 inch diameter.

- Large capacity: Interchangeable hook feature means that Tor can replace two or more similar products in the toolbox.
- Easy to use: Positive locking positions for circular, lengthways and spiral strips.
- The blade automatically returns to its starting position at the end of a strip reducing the possibility of broken blades.
- No special tools are required to change hooks – one replaces the other. The blade height adjustor is almost friction free and is easy to rotate for fine blade height adjustment.
- Safety straps can be fixed to the eyelet at the base of Tor to prevent accidental dropping of the tool.
- Ergonomic: The well balanced design features rests for thumb, first and little fingers to ease raising of the cable retention hook.
- Durable: Replacement cutting blades can be stored in a pocket located within the tool.
- Tor has been tested to over 100,000 cycles.

TECHNICAL DATA

Length: 167 mm/6.57"

Width: 37 mm/1.46"

Height: 30.5 mm/1.2"

Weight: 116 gr/0.26 lb

Wire size: 4.5-40 mm / 0.18"-1.57"

Stripping dimensions mm/mm²:
adjustable/up to 4,5 mm (insulation thickness)

Stripping dimensions inch/AWG:
adjustable/up to 0.18" (insulation thickness)

Cable: PVC

Description: Adjustable stripping tool for power cable, multi-conductor control, fiber optic and copper trunk cables.

Life span, cycles: 100,000



Circular • straight strip, window strip and circular • spiral strip.

Replacement blade

